## **Superposition Principle**

"The net drawdown or rise caused by n-wells (i.e., some pumping and some injecting) at a location of interest is equal to the algebraic sum of the individual drawdowns or rises or both."

This principle applies to both unconfined and confined aquifers.

$$S_{net} = \sum_{i=1}^{n} S_{i}$$